

**DTS Modbus Addendum (SunSpec)  
Version R22A****TABLE OF CONTENTS**

1	SCOPE .....	2
1.1	IDENTIFICATION.....	2
1.2	INTRODUCTION .....	2
2	SunSpec Alliance Modbus Map.....	3
2.1	Introduction .....	3
2.2	SunSpec Data Types .....	4
2.3	Scaling Factors for Power and Energy .....	5
3	DTS Sub Meter AC SunSpec Map .....	6
3.1.1	DTS Sub Meter AC Common Model SunSpec Map Details.....	6
3.1.2	DTS Sub Meter AC Integer Model SunSpec Map Details.....	7
3.1.3	DTS Sub Meter AC Floating Point SunSpec Map .....	9
4	DTS Sub Meter DC SunSpec Map .....	11
4.1.1	String Combiner Details.....	11
4.1.2	DTS Sub Meter DC SunSpec Map Details.....	12

## 1 SCOPE

### 1.1 IDENTIFICATION

This document describes additional Modbus Register information as specified by SunSpec Alliance, over and above that detailed in the standard Modbus Map document.

This document applies to models **DTS 305**, **DTS 307**, **DTS 310**, **DTS SMX**, **DTS SKT**, and **DTS DC**.

### 1.2 INTRODUCTION

The **Standard DTS Modbus Map document** should be studied before attempting to use any of the **advanced** registers described in this document.

In particular, the **Introduction**, and **General Information** sections on **Modbus Registers** (data types and size, register order, and area), and **Power and Energy Register Resolutions** should be fully understood.

The DTS range of meters support the SunSpec Alliance Modbus Specification. See [www.sunspec.org](http://www.sunspec.org) for more information. The SunSpec Alliance Modbus map has been available in AC Meters from firmware V2.61, and in DC Meters from firmware V2.65. The SunSpec floating-point meter model is available for AC meters from firmware V2.93.

### NOTE

Capabilities are model dependant, so some registers may not be applicable or relevant to certain models.

This document lists the SunSpec measurement quantities that are available for the DTS range of meters. Measurement quantities that are not available return the SunSpec "Not Available" value.

The base register address for the SunSpec Alliance Modbus Map is at 50001 for all the DTS meters.

## 2 SunSpec Alliance Modbus Map

### 2.1 Introduction

SunSpec register order for **32-bit Integer** and **Floating Point** values is **HI-LO**, therefore, the 16-bit Modbus register at the address given in the Modbus map below is the **HI** register, and the next consecutive 16-bit Modbus register is the **LO** register. *Note that this is opposite to the **LO-HI** register order for the standard Modbus registers in the DTS meters.*

Unless stated otherwise, our published Modbus registers addresses are all **1-Based** addresses in the **“Holding Registers”** in the **4x region**, as per the Modbus recommendations. Depending on your Modbus Master application, you may need to prefix the Modbus address with a **‘4’**. Some Modbus Master applications may also require **0-based** Modbus addresses, in which case, simply subtract one from the Modbus registers addresses shown in this document. Note that the Modbus Master application must support 5-digit register numbers. Here are some examples to illustrate these issues:

Meter Register Name	Modbus Address As Shown In This Document	1-Based Modbus Address With ‘4’ Prefix	0-Based Modbus Address With ‘4’ Prefix
AC_Voltage_LL	50081	<b>450081</b>	<b>450080</b>
AC_Current	50072	<b>450072</b>	<b>450071</b>
AC_Power	50088	<b>450088</b>	<b>450087</b>

All SunSpec Alliance registers begin at the conventional 1-based Modbus address of 50001 in the Modbus “Holding Register” region, regardless of the meter model.

## 2.2 SunSpec Data Types

The following data types are used in the SunSpec models as represented in the table below:

- uint16: 16-bit unsigned Integer value (one Modbus register).
- acc32: 32-bit Integer accumulated values. Used for ever increasing values that may roll over. This is a double Modbus register, and the register order is HI-LO.
- float32: 32-bit Floating Point value. A double Modbus register is needed for floating point values, and the register order is HI-LO.
- sunssf: SunSpec Alliance scaling factor. The sunssf is a signed 16-bit two's compliment integer, in the range [-10 10], which represents the intended resolution of the register value as an exponent of 10 (or  $10^{\text{sunssf}}$ ).

Effectively, the scaling factor explicitly shifts the decimal point to the left (for negative values) or the right (for positive values).

Or more mathematically, to convert the value read from any register, multiply the value by the resolution for that group of registers, which is just multiply by  $10^{\text{sunssf}}$ .

Fixed scaling factors are shown in the tables. Power and energies have variable scaling factors (See 2.3 for further details).

### For example:

The voltages and currents in our SunSpec map all have a 0.1 resolution, so the sunssf values at 50076 and 50085 respectively are both -1. Therefore, if a voltage register contains the value 1203, then the scaled value is  $1203 * 10^{-1} = 1203 * 0.1 = 120.3V$ .

- bitfield: A collection of bits, multi-valued alarms or states.

## 2.3 Scaling Factors for Power and Energy

The SunSpec Integer Meter Models make use of Scaling Factors (sunssf) to represent the implied decimal point for the various groups of the Integer registers, so that a wide range of measurement quantities can be handled.

Some of these Scaling Factors are fixed for the DTS meters, and do not vary. Since these are constant, they are explicitly shown in the tables below. Quantities such as Voltage, Current, Frequency and Power Factor fall into this category.

However, the range of values for Power and Energy can vary so widely that it is impossible to have a fixed Scaling Factor for these quantities. The Scaling Factor for these quantities is shown as "Varies" in the tables below.

The Scaling Factors for Power and Energy are determined from the service configuration of the meter (PT and CT ratios). Please see our standard Modbus Map documentation (Section 2.1.3) for details on the *"Power and Energy Register Resolutions and Roll Over"* for the DTS range of meters. This service configuration is generally setup only once when the meter is commissioned, and will not change after that. Therefore, the applicable Scaling Factors for the Power and Energy will vary in order to match the service configuration, but are fixed thereafter and do not change dynamically.

For example, if a 3-Phase WYE service has a Line-Neutral Voltage of 120V and a rated current of 200A, then the total power for that service is  $3*(120*200) = 72\text{kW}$ . From the table in section 2.1.3 of our standard Modbus Map documentation, it can be seen that this service falls into the range "*10 kW to 100 kW*", so the resolution for all Powers and Energies in the native DTS Modbus registers will be 1W.

This same 1W resolution is also used for all the Energies in the SunSpec map, so sunssf=0 in this example.

However, the Power registers in the SunSpec Modbus map are only "int16" (signed 16-bit integer) registers. This means that these registers can only represent Integer numbers in the range [-32,768 .. 0 .. 32,767], so clearly the total power of 72,000W in this example cannot be represented. Therefore, the Scaling Factor for all Powers in the SunSpec Integer Meter Models is 10 times courser than that of the Energies. In this example, the resolution for the Powers would be 10W, so sunssf=1.

### Note

This limitation for the Power resolutions does NOT apply to the SunSpec Floating-Point Model, and the full native DTS resolution is available for both the Power and the Energy registers. Floating point values are also much more convenient because the measurement quantities are all represented in unary units, and no Scaling Factors are required.

## 3 DTS Sub Meter AC SunSpec Map

The AC SunSpec map can be broken into different models:

"SunS" Identifier
Common Model
Integer Meter Model
Floating Point Meter Model
End Model

The floating-point model is positioned **after** the integer model, so any applications that use specific fixed Modbus addresses in the existing integer model will not be affected. Note that the floating-point values are derived from our standard measurements registers in the DTS meter, so will have the exact same resolution as specified in our standard Modbus Map documentation.

The DTS 305, DTS 307, DTS 310, DTS SMX and DTS SKT range of AC meters are SunSpec Alliance compliant.

The DTS AC meters contain the following SunSpec Models:

Block Type	Address	Len	SunSpec Block IDs	SunSpec Version
32-Bit "SunS" Identifier (SID)	50001 - 50002	-	0x53756E53	1.4
Common Block	50003 - 50069	65	1	1.4
Integer Meter Model Block	50070 - 50176	105	201, 202, 203, 204	1.4
Floating Point Meter Model Block	50177 - 50302	124	211, 212, 213, 214	1.4
End Block (Firmware V2.92 and Earlier)	50177 - 50178	0	0xFFFF	1.4
End Block (Firmware V2.93 and later)	50303 - 50304	0	0xFFFF	1.4

### 3.1.1 DTS Sub Meter AC Common Model SunSpec Map Details

SunSpec Identifier	Modbus Address	
Description		Register Value
SID	"SunS"	50001

Common Model	Modbus Address	
Description		Register Value
ID	1	50003
Length	65	uint16
Manufacturer		uint16
Model		uint16
Options		uint16
Version		uint16
SerialNumber		uint16
Device_Address		uint16

### 3.1.2 DTS Sub Meter AC Integer Model SunSpec Map Details

<b>Integer Model</b>	<b>Modbus Address</b>		
<b>Description</b>		<b>Units</b>	<b>Register Value</b>
ID	201/202/203/204	50070	uint16
Length	105	50071	uint16
AC_Current	50072	A	uint16
AC_Current_A	50073	A	uint16
AC_Current_B	50074	A	uint16
AC_Current_C	50075	A	uint16
AC_Current_SF	-1	50076	sunssf
AC_Voltage_LN	50077	V	uint16
AC_Voltage_AN	50078	V	uint16
AC_Voltage_BN	50079	V	uint16
AC_Voltage_CN	50080	V	uint16
AC_Voltage_LL	50081	V	uint16
AC_Voltage_AB	50082	V	uint16
AC_Voltage_BC	50083	V	uint16
AC_Voltage_CA	50084	V	uint16
AC_Voltage_SF	-1	50085	sunssf
AC_Freq_A	50086	Hz	uint16
AC_Freq_SF	-2	50087	sunssf
AC_Power	50088	W	uint16
AC_Power_A	50089	W	uint16
AC_Power_B	50090	W	uint16
AC_Power_C	50091	W	uint16
AC_Power_SF	Varies	50092	sunssf

<b>Integer Model (Continued)</b>	<b>Modbus Address</b>		
<b>Description</b>		<b>Units</b>	<b>Register Value</b>
AC_VA	50093	VA	uint16
AC_VA_A	50094	VA	uint16
AC_VA_B	50095	VA	uint16
AC_VA_C	50096	VA	uint16
AC_VA_SF	Varies	50097	sunssf
AC_VAR	50098	VAR	uint16
AC_VAR_A	50099	VAR	uint16
AC_VAR_B	50100	VAR	uint16
AC_VAR_C	50101	VAR	uint16
AC_VAR_SF	Varies	50102	sunssf
AC_PF	50103	Pct	uint16
AC_PF_A	50104	Pct	uint16
AC_PF_B	50105	Pct	uint16
AC_PF_C	50106	Pct	uint16
AC_PF_SF	-1	50107	sunssf
Exported	50108	Wh	acc32
Imported	50116	Wh	acc32
Energy_W_SF	Varies	50124	sunssf
Exported_VA	50125	Wh	acc32
Imported_VA	50133	Wh	acc32
Energy_W_SF	Varies	50141	sunssf
Imported_VARh_Q1	50142	Wh	acc32
Imported_VARh_Q2	50150	Wh	acc32
Exported_VARh_Q3	50158	Wh	acc32
Exported_VARh_Q4	50166	Wh	acc32
Energy_VAR_SF	Varies	50174	sunssf
Events	50175		uint16
Events	50176		uint16

### 3.1.3 DTS Sub Meter AC Floating Point SunSpec Map

Floating Point Model	Modbus Address	Units	Register Value
Description			
ID	211/212/213/214	50177	uint16
Length	124	50178	uint16
AC_Current	50179	A	float32
AC_Current_A	50181	A	float32
AC_Current_B	50183	A	float32
AC_Current_C	50185	A	float32
AC_Voltage_LN	50187	V	float32
AC_Voltage_AN	50189	V	float32
AC_Voltage_BN	50191	V	float32
AC_Voltage_CN	50193	V	float32
AC_Voltage_LL	50195	V	float32
AC_Voltage_AB	50197	V	float32
AC_Voltage_BC	50199	V	float32
AC_Voltage_CA	50201	V	float32
AC_Freq_A	50203	Hz	float32
AC_Power	50205	W	float32
AC_Power_A	50207	W	float32
AC_Power_B	50209	W	float32
AC_Power_C	50211	W	float32
AC_VA	50213	VA	float32
AC_VA_A	50215	VA	float32
AC_VA_B	50217	VA	float32
AC_VA_C	50219	VA	float32


<b>Floating Point Model (Cont)</b>	<b>Modbus Address</b>		
<b>Description</b>		<b>Units</b>	<b>Register Value</b>
AC_VAR	50221	VAR	float32
AC_VAR_A	50223	VAR	float32
AC_VAR_B	50225	VAR	float32
AC_VAR_C	50227	VAR	float32
AC_PF	50229		float32
AC_PF_A	50231		float32
AC_PF_B	50233		float32
AC_PF_C	50235		float32
Exported	50237	Wh	float32
Imported	50245	Wh	float32
Exported_VA	50253	Wh	float32
Imported_VA	50261	Wh	float32
Imported_VARh_Q1	50269	Wh	float32
Imported_VARh_Q2	50277	Wh	float32
Exported_VARh_Q3	50285	Wh	float32
Exported_VARh_Q4	50293	Wh	float32
Events	50301		uint16
Events	50302		uint16

The "End Model" designates the end of the SunSpec structure.

<b>End Model</b>	<b>Modbus Address</b>		
<b>Description</b>		<b>Units</b>	<b>Register Value</b>
ID	65535	50303	uint16
Length	0	50304	uint16

## 4 DTS Sub Meter DC SunSpec Map

The DC SunSpec map can be broken into different models:



The DTS DC range of AC meters are SunSpec Alliance compliant.

The DTS DC meters contain the following SunSpec Models:

Block Type	Address	Len	SunSpec Block IDs	SunSpec Version
32-Bit "SunS" Identifier (SID)	50001 – 50002	-	0x53756E53	1.4
Common Block	50003 – 50069	65	1	1.4
Advanced String Combiner Model Block	50070 – 50096	25	404 (N=0)	1.2
End Block	50097 – 50098	0	0xFFFF	1.4

### 4.1.1 String Combiner Details

The following data elements are provided to describe string combiners (SC). This model supports a variable number of string combiner inputs.

- **ID** – A well-known value that uniquely identifies this block.
- **Length** – The length of the string combiner block in registers.
- **DC\_xxxx** – DC values.
- **Event\_xxxx** – Event Flags
- **InDC\_xxxx** – Input values

## 4.1.2 DTS Sub Meter DC SunSpec Map Details

<b>SunSpec Identifier</b>	<b>Modbus Address</b>	
<b>Description</b>		<b>Register Value</b>
SID	"SunS"	50001
		uint16

<b>Common Model</b>	<b>Modbus Address</b>	
<b>Description</b>		<b>Register Value</b>
ID	1	50003
Length	65	50004
Manufacturer		50005
Model		50021
Options		50037
Version		50045
SerialNumber		50053
Device_Address		50069
		uint16

<b>DC Model</b>	<b>Modbus Address</b>		
<b>Description</b>		<b>Units</b>	<b>Register Value</b>
ID	404	50070	
Length	25	50071	
DCA_SF	-1	50072	
DCAhr_SF	-3	50073	
DCV_SF	-1	50074	
DCW_SF	Varies	50075	
DCWh_SF	Varies	50076	
DCAMax Maximum Current		50077	A
Number of Inputs (N)	0	50078	count
Event		50079	bitfield32
Vendor Event		50081	bitfield32
DCA		50083	A
DCAhr		50084	Ah
			acc32

<b>DC Block (Continued)</b>	<b>Modbus Address</b>		
<b>Description</b>		<b>Units</b>	<b>Register Value</b>
DCV	50086	V	uint16
DCW	50088	W	acc32
DCWh	50090	W	uint16
InDCA_SF	-1	50092	sunssf
InDCAhr_SF	-3	50093	sunssf
InDCV_SF	-1	50094	sunssf
InDCW_SF	Varies	50095	sunssf
InDCWh_SF	Varies	50096	sunssf

The "End Model" designates the end of the SunSpec structure.

<b>End Model</b>	<b>Modbus Address</b>		
<b>Description</b>		<b>Units</b>	<b>Register Value</b>
ID	65535	50097	uint16
Length	0	50098	uint16